


AirWave



Recommended Settings

PlantWave for Nano4PRO

PlantWave			
	Speed	Temperature %	Air %
9.7.1 / 7.1*	V4	30-35	13-15
	V3	28-32	
	V2	25-27	
	V1		
9.8.3 / 8.3*	V4	35-38	70-75
	V3	28-32	60-65
	V2	25-27	50-55
	V1	20-23	40-45

The listed settings are recommendations to ensure a longer life of the machine by still good cushion results. Do not exceed these settings. But temperature and air volume can differ a little bit depending on field of application and environmental conditions.

*** Use (white) distance ring for AirWave original lengths rolls (7.X and 8.X)**